

**BrightSign®**

# FIRMWARE RELEASE NOTES

Version 4.4.82 (BrightSign XD230, XD1030, XD1230)

## Updating your BrightSign Software

1. Download the Brightsign Software update.zip file.
2. Unzip it and copy update.bsfw to the root of your SD card using your PC and a card reader.
3. Power off the BrightSign player.
4. Place your card into the SD slot of the BrightSign player.
5. Power on the BrightSign player. The player software will update and restart automatically.

## Changes Since 4.4.75

### Note

Unless marked by a ✓ symbol, new features listed in these release notes are not available in the current beta or release version of BrightAuthor and can only be utilized with custom scripts. A feature may become available through BrightAuthor at a later date. Please refer to the BrightAuthor release notes for all new features and functionality made available in BrightAuthor.

### New Features

- ✓ RF diagnostics and channel scanning capabilities are now available on the [Diagnostic Web Server](#).

### Bug Fixes

- Javascript/HTML widgets now display time using the correct designated time zone.

- Switching from a presentation in 3D mode to a presentation in 2D mode no longer causes problems with video resolution.
- Multiple zones with Live Text no longer encounter intermittent flickering issues.
- There have been numerous fixes and improvements for touch screens.
- Players no longer attempt to retrieve an AutoIP address when the Ethernet interface is disconnected.

## Improvements

- Players support the Samsung ME40B touch screen.
- uPnP (Universal Plug and Play) events can now be received over the network connection.